


MEMORY HANDSET MANUAL



Wake: To wake press any button.

Calibrate or Reset: PRESS/HOLD 15 seconds LED Display shows HOLD until Display shows RELEASE then Display shows 60.

GLP: stands for Go to Lowest Position. This means your desk must be re-calibrated.

CON: stands for Connection. One of the frame legs are not working properly. Unplug the device and plug it back in.

HIT: stands for HIT. This protects your desk against collisions that could lead to damage. if something hits your frame while it is raising or lowering, it will automatically stop and Memory Handset will read

OH: stands for Overheat. This will show up if the desk has had two minutes of constant usage. To resolve, wait 15 minutes for your desk to cool down.

OLU: stands for Overload, this means there is too much weight on your frame. Either remove some weight or change the load capacity on your frame in setting

Set Preferred Heights: ADJUST to 1st preferred height
PRESS PRESS REPEAT steps for remaining settings.

Set Max Height: PRESS/HOLD 15 seconds RELEASE WHEN LED Display blinks PRESS/HOLD
When desk raises to highest point (120 CM) RELEASE PRESS LED Display shows

Set Min Height: PRESS/HOLD 15 seconds RELEASE WHEN LED Display blinks PRESS/HOLD
When desk reaches lowest point RELEASE PRESS LED Display shows

Set Max/Min Load Capacity: PRESS/HOLD 20 seconds LED Display will show PRESS ADJUST max/min load capacity using OR
PRESS to exit or PRESS then PRESS OR to choose a different (P) setting

Measurement Conversion: PRESS/HOLD 20 seconds LED Display will show PRESS once to show PRESS
PRESS OR to go from inches (1) and cm (0) PRESS to exit or
PRESS then PRESS OR to choose a different (P) setting

Collision Sensitivity: PRESS/HOLD 20 seconds LED Display will show PRESS twice to show
PRESS PRESS OR to adjust sensitivity (5-30) 15 is standard, lower the number the more sensitive.

Feel free to reach out with any questions, comments, or concerns.
We are always happy to help!

www.standdesk.co/contact

INITIALIZING YOUR STANDDESK

YOU MUST INITIALIZE YOUR STANDDESK BEFORE USE!

Press and hold the down arrow for 15-30 seconds.

As you hold the button, the frame will go down to its lowest position, and then calibrate.



OR



**PRESS
AND HOLD
15-30 SEC**

**PRESS
AND HOLD
15-30 SEC**